




## CD Burning Instructions


1. Place a blank CD in the **ionit** DVR (close the window that pops up).
2. From the main screen click **PLAY**.




3. Then click **Files Mode**.



4. In the file tree, click on + sign next to **ionitPRO+ Host**. Check under the Storage: drives for desired date folder (i.e. 2007/02/28) and click on the **Video** folder, or **Clip** folder if you made a clip. **NOTE:** Video for a particular day may be divided onto two drives.



5. Highlight the video file(s) to be copied and click **Burn** on the toolbar at the top of the screen. **NOTE:** Select multiple files by holding down the control or shift key while clicking on desired files.
6. The following window will appear. Click **Start Burn**.



7. Click **OK** and either burn more video or eject the CD using the CD eject button on the DVR. The **ionit** player (called VG\_Player.exe) will automatically be burned to the CD.

